




INSTRUCTION SHEET

This livestock watering bowl has a proper lifting procedure. "DO NOT" attempt to place bowl without proper lifter(s) part # C-Lft. Waterers can be lifted with a single chain attached lifter(s) which is inserted through the balance point of the waterer or the center hole in cattle trough, and secured with a heavy washer or nut. Models using 2 lifters need to be lifted using bale forks or teeth on bucket as a spreader bar so that it is lifted evenly on both sides.



It is recommended that all waterers be installed on a concrete platform. The waterer should be set on a bed of mortar on a clean, level platform. The mortar should be finished smooth around the outside of the waterer. If the platform is not completely level, shim the waterer to make it level and work mortar under waterer to seal out wind, cold and water, and to hold waterer in place. (Old platforms should be clean and dampened when applying new mortar). Store bottom side down. Warranty void if waterer placed on side. New installations can be supported on timbers or railroad ties for the first year and the area fixed and put in pad after the settling has taken place. A pad 4" thick with corners cut at 45 degrees either 8' x 8' so just the animal's front feet end up on pad or 16' x 16' so the entire animal stands on the pad. For a riser pipe we suggest no less than 8" in diameter plastic pipe. Riser line should be cut off 2" above the cement pad to stop water from seeping under the bowl and down into the pipe.




WATER HOOKUP

This waterer has the hose hookup attached and after placement of the bowl, hook the incoming water line to the male thread hose fitting (Teflon tape may be used to ensure no leaking). The other end of the hose hookup is attached to the valve. Remove the threaded arm from the parts bag (attached to the aux element bracket) and attach one end to the stainless steel float ball and the other end to the valve arm. Loosen the wing nut on the valve to set the level of the float ball in the water bowl. Note: do not power up water bowl until full of water, as the thermostat may turn on elements and elements may split from sitting in open air.


ELECTRIC HEAT

When using electric heat, be sure to make provisions for grounding waterer before setting waterer over pit or tile. A ground rod is required, driven down inside the tile or pit. (Local electrical codes should be checked). The riser pipe in the waterer can be wrapped with a short heat tape. (Heat tapes not included with waterer). Heat tapes without thermostats may be hooked into thermostat on the waterer at time of electrical hookup. Auxiliary heaters are standard on all our waterers. Auxiliary heater should be located so as to "not" allow contact with insulation, electrical wiring, water line and set on concrete base in bracket. Always check voltage. Be sure wiring is installed to meet all safety requirements of local code. Use correct amp fuse or breaker. Caution: make sure waterer is grounded to meet requirements of local code.



CANCRETE CONTINUOUS FLOW DRAIN LOCATIONS

(Note* if an end hood model measurement is correct
from center of riser.)




AUTO CONTINUOUS FLOW

If you have purchased a Concrete water bowl with "Auto Continuous Flow" you should be aware of a couple of maintenance items that will make this experience a good one! Most people are now using large diameter riser pipes, and these, in some Southern areas bring up a great deal of ground heat. The top sensor does not differentiate between ambient air temperature and ground heat so it may turn on and stay on when it shouldn't be running. If this happens, turn off, the ball valve that is located under the top sensor or put a bit of insulation in the chimney to stop ground heat from coming up. This is typically not an issue until late February or Mid-March when temp sits around 38 - 40F. As always if any of the use of this system confuses you call our toll free number and we will walk you through the use of the system.

ADJUSTMENTS AND MAINTENANCE

Thermostat - Thermostat is preset at full on position. Although during shipment and handling, the setting may become altered and must be reset. Caution should be taken when resetting, one complete turn of the adjusting cap on thermostat changes the temperature setting 60F degrees. There is a stop on the knob dial and forcing past the stop ruins the thermostat. To **raise the temperature** setting turn adjusting cap **counterclockwise** (as if removing a screw). To **lower temperature** setting turn **clockwise**.



If thermostat fails during freezing weather, water may be kept ice-free by wiring direct.

1. Disconnect electric power to waterer.
2. Disconnect thermostat.
3. Wire heater element direct.
4. Replace thermostat as soon as possible.

In the event the thermostat sticks or fails to function, which can occur after several years in service or after a period of non-use, turn adjusting cap 1/4 turn each way a few times. In many instances, this will activate the points and the thermostat will function properly. If after this procedure the thermostat still does not work, it will have to be replaced. **Caution:** thermostat is screwed into a 1/2" brass coupling and when replacing should be turned only a little more than hand tight. Counterclockwise raises temperature setting.

Electrical heater elements should be cleaned periodically to prevent lime and scale buildup, extending life of the heater and adding to greater heater efficiency. To test heater element remove marrette from thermostat wire connection and direct wire the element bypassing the thermostat. Heater will get hot if working correctly. Be sure that wiring is properly installed to meet all electrical code safety requirements.

Should you choose to clean manure or ice and snow off the water bowl pad with a front-end loader and subsequently hit your water bowl and collapse the side wall . . . there will be no warranty, so use caution.

PRECAST CONCRETE CATTLE WATERER WARRANTY

Advanced Agri-Direct Inc. (hereafter referred to as the "supplier") cattle waterer hulls are warranted against defects in the materials and workmanship, and will perform according to our specification provided that installation is proved to be satisfactory to the supplier.

In the event that the concrete hull proves defective, during the first 3 years, it will be replaced free of charge (F.O.B. our yard) to the original owner or repaired upon the supplier option. The remainder of the warranty period will provide to the original owner a rebate against the replacement of the waterer hull equal to 20% of the original cost of the hull. This rebate will only be applied to the cost of the replacement hull.

Permission to replace, alter, or repair must first be obtained from the supplier. Labor costs, transportation or any other extraneous costs will not be allowed.

This warranty does not include replacement of any materials lost through leakage, or damages arising therefrom.

The supplier does not assume liability for a hull damaged or made defective because of improper installation, improper usage, negligence, or for a hull damaged by any other cause. Furthermore, the supplier also assumes no liability for any consequential damage to persons, property or the environment due to discharge from a hull. We do not assume, nor do we authorize any other person to assume for us, any other responsibility to this purchase. The term "original owner" as used in this warranty is understood to mean the person who originally requested the installation of the tank on his property and the term "original installation" shall mean the first installation of such tank on such property. Warranty void if waterer is placed on side. Only store bottom down.

Warning: install on non-combustible surface.

ELECTRONICS AND COMPONENTS WARRANTY

Advanced Agri-Direct Inc. (hereafter referred to as the "supplier") warrants all COMPONENTS and electrical parts and workmanship to be free from manufacturing defects, for a period of 1 year from date of original installation.

At the option of the supplier, replacement parts may be sent to the original owner, and the installation of those replacement parts will be the responsibility of the original owner. Parts sent to the supplier for repair or replacement must be sent to the supplier shipping prepaid. parts will be returned shipping collect.


The supplier's total obligation under this warranty shall be limited to the repair of defects or replacement of defective parts as outlined above. The supplier assumes no other responsibility whatsoever. If the failure of the parts is due to misuse, abuse, in transit or in process of installation, replacement becomes the responsibility of the original owner. There is no other warranty, written or verbal, pertaining to waterer COMPONENTS and parts.

Note: Top elements are immersion elements. If it splits, it has been out of water for a substantial amount of time. This is not a warrantable situation. An immersion element can also split if it develops a substantial amount of buildup on the element from exceptionally dirty water (dugout). This can be scraped off to stop this condition.


CONCRETE WATERER TROUBLESHOOTING GUIDE

PROBLEM	SOLUTION
<i>Where does auxiliary element go?</i>	On your pad under bowl (DO NOT put down riser pipe). If bowl is on timbers, set on block of wood.
<i>Waterer freezing</i>	Check the thermostat setting, turning it counterclockwise (left) increases temperature. If under bowl and 4" riser, heat with heat tape.
<i>Element doesn't heat up after being off for a period of time</i>	Turn thermostat back and forth (Note: only goes one full turn), this will loosen a stuck contact.
<i>Cattle lapping water out making mess or ice around bowl</i>	Turn temperature down. Cattle don't like hot water and will lap it out and wait for cold water to come in. (See excessive ice buildup also)
<i>Water has excessive ice buildup in bowl in freezing temperatures</i>	Lower water level to just above holes on hood in winter. It will stop this and save energy (less water to heat). Adjust thermostat in small increments. (See cattle lapping water also)
<i>Valve freezing at elbow</i>	Check if auxiliary element is hooked up and working under the bowl. This sends heat up through the chimney to the valve.
<i>Elements not heating</i>	Check power at bowl, (See item #2) bypass thermostat. If all else fails, put power to each side of element, if the element doesn't heat it needs to be replaced. Replace split or faulty elements.
<i>Valve seeps causing bowl to overflow</i>	Check float ball setting. If waterer has been in place for some time, take valve apart and clean. ALL water causes buildup on rubber seals. Replace if necessary.
<i>How to move or lift waterer</i>	Use a proper lifter. Lifter is a simple eyebolt 3/4" or larger with a flat plate 3" x 3" under bowl with a nut. Lift with chain and front end loader.
<i>Clean-out plug leaks</i>	Pound in with rubber mallet, dry hole first, to ensure proper seal.
<i>Thread on hood bolts stripped or ruined</i>	Replace with new studs. These are stainless, replaceable and almost impossible to re-thread. Vise grip will remove old one. If turned too far will break out the bowl concrete.
<i>Plastic float ball heat damaged</i>	Bowl has been drained of water, either power was off or supply problem. Using Kerick valve with min. 20 lb. pressure, you can't get enough cattle to drink it down. Replace plastic float ball with stainless steel.
<i>Sealing bowl to pad</i>	In most cases within one day the cattle bring mud and manure onto the pad and it seals. You can seal with cold application tar BEFORE setting bowl in place.
<i>Power failure or burned out element, bowl is frozen</i>	Do not use heavy object to break out ice to remove element (such as axe, sledge hammer, etc.), hulls are hollow and the bottom will break out or crack. Instead use an alternative heat source to melt the ice and then remove and replace element.

REORDER PARTS LIST

 PT75LS 3/4" Valve PT1000LS 1" Valve	 TRI 250 250 WATT Element TRI 700 700 WATT Element TRI 1000 1000 WATT Element	 SSVHLG Valve Cover LARGE
 H31436 3/4" Complete Hose H136 1" Complete Hose	 U300C 300 WATT Element	 SSVHSM Valve Cover SMALL
 AH-6SS 6" S/S Float	 TRI 98 Auxiliary Element	 VPI25 3/4" Valve with 3/8" Orifice
 R10-35 R10-4 S/S Arm 3.5" & 4"	 EBT8 Terminal Block	 SSDO S/S Service Door
 14130W #15 Drain Plug	 FM344 Thermostat	 SSEBT S/S Element Bracket & Tab
 14130J #6 Lifter Plug	 SYIN Door Insert	 SSEB S/S Electrical Bracket
 LFT Lifter Bolt w/Nut	 SS STUD S/S/ Stud	 EBAC Complete Electrical Box
 SSFW38 S/S Flat Washer 3/8"  SSN38 S/S Nut 3/8"  SSB38X175 3/4" Bolts B2238.34 1-3/4"	 SF75/CF100 Continuous Flow Valve	 SSVB S/S Valve Bracket

COMPLETE VALVE



PPT-55881
PPO-55881
Touch Up Coating
Teal/Orange



DAP00688

Repair Sealant



AVAILABLE MODELS



CGSA50



CESA50



CDESA50



C150



C250



C350



C450



C75SWEM



C550 "The Bad Boy"



CS75




D800 Dairy and Big Feeder Bowl

EASY PAD SPECS



**8000 PSI
DRY POUR
PRECAST
CONCRETE**



**3/4" THREADED
INSERTS c/w EYEBOLTS
FOR LIFTING**
**FORK LIFT SHIMS OR
ACCESS FOR BALE HOOKS**
Weight 2600 lbs.

Model	No. of Head Feeder Cattle	No. of Head Cows	Dimensions	Weight
CGSA50	N/A	50 Goats or Small Animals	21 1/4"L x 24 1/4"W x 14" H	260 lbs
CESA50	N/A	50 Horses or Small Animals	22"L x 24 7/8"W x 18" H	320 lbs
CDESA50	N/A	60 Horses or Small Animals	36"L x 27"W x 18" H	460 lbs
C150	1 - 200	0 - 50	33"L x 36"W x 25"H	800 lbs
C250	200 - 300	50 - 120	37"L x 36"W x 25"H	1000 lbs
C350	300 - 400	120 - 220	43"L x 36"W x 25"H	1100 lbs
CS75	400 - 500	220 - 350	78"L x 36"W x 25"H	1400 lbs
C75SWEM	400 - 500	220 - 350	78"L x 36"W x 25"H	1400 lbs
C450	400 - 500	220 - 350	69"L x 36"W x 25"H	1300 lbs
C550	500 - 600	350 - 500	93"L x 36"W x 25"H	1850 lbs
D800	600 - 800	500 - 650	168"L x 36"W x 25"H	3300 lbs



710 WEST 26TH STREET

YORK, NEBRASKA 68467-96

TEL: (402) 362-0122

FAX: (402) 362-6148